# Sigma-Aldrich

Technical Bulletin

## Isocitrate Assay Kit

#### Catalogue number MAK524

## **Product Description**

Isocitrate (Isocitric acid) is a substrate in the citric acid (TCA) cycle. Isocitrate is formed by the isomerization of citrate catalyzed by the enzyme aconitase. Isocitrate is oxidized by isocitrate dehydrogenase producing a ketoglutarate and generating NADPH. Isocitrate is commonly found in many fruits and vegetables and their processed products.

The Isocitrate Assay Kit measures the NADPH generated from the oxidation of isocitrate. The NADPH converts the dye to an intense violet color with an absorption maximum at 565 nm. The increase in absorbance at 565 nm is directly proportional to the isocitrate concentration.

The linear detection range of the kit is 20 to 5000  $\mu$ M isocitrate. The kit is suitable for determination of isocitrate in food, beverage, and biological samples such as cell lysate, tissue homogenate and serum.

#### Components

The kit is sufficient for 100 colorimetric assays in 96-well plates.

•	Assay Buffer Catalogue Number MAK524A	10 mL
•	Enzyme A Catalogue Number MAK524B	120 µL
•	Enzyme B Catalogue Number MAK524C	120 µL
•	NADP/MTT Catalogue Number MAK524D	1 mL
•	Standard (100 mM) Catalogue Number MAK524E	1 mL

## Equipment Required but Not Provided

- Pipetting devices and accessories (for example, multichannel pipettor)
- Spectrophotometric multiwell plate reader.
- Clear bottom 96-well plates. Cell culture or tissue culture treated plates are not recommended.
- 1.5 mL microcentrifuge tubes
- Dounce tissue grinder set. (Catalogue Number D9063 or equivalent)

#### Precautions and Disclaimer

For R&D use only. Not for drug, household, or other uses. Please consult the Safety Data Sheet for information regarding hazards and safe handling practices.

## Storage/Stability

The kit is shipped on wet ice. Store all components at -20 °C.

## **Preparation Instructions**

Briefly centrifuge small vials before opening.

Keep Enzyme A and Enzyme B thawed enzyme on ice. Equilibrate all other components to 25 °C prior to use.



#### Procedure

All Samples and Standards should be run in duplicates.

## Sample Preparation

All Samples can be stored at -20 °C to 80 °C for at least one month.

#### Tissue:

- 1. Prior to dissection, rinse tissue in phosphate buffered saline (pH 7.4) to remove blood.
- 2. Homogenize 50 mg of tissue in  $\sim$  200  $\mu$ L of buffer containing 50 mM potassium phosphate (pH 7.5).
- 3. Centrifuge at 10,000 ×g for 15 minutes at 4 °C.
- 4. Remove supernatant for assay.
- 5. Transfer 20 µL of each sample into separate wells.

#### Cell Lysate:

1. Collect cells by centrifugation at 2,000  $\times$  g for 5 minutes at 4  $^{\circ}$ C.

**Note:** For adherent cells, do not harvest cells using proteolytic enzymes. Instead, use a rubber policeman.

- 2. Homogenize or sonicate cells in an appropriate volume of cold buffer containing 50 mM potassium phosphate (pH 7.5).
- 3. Centrifuge at 14,000 × g for 10 minutes at 4 °C.
- 4. Remove supernatant for assay.
- 5. Transfer 20  $\mu$ L of each Sample into separate wells.

#### Standard Curve

- 1. Prepare 200  $\mu$ L 5000  $\mu$ M Premix by mixing 10  $\mu$ L of the Standard (100 mM) with 190  $\mu$ L purified water.
- Dilute standards in 1.5 mL centrifuge tubes as described in the Table 1.

**Table 1.** Standards Preparation

Well	Premix	Purified Water	Isocitrate (µM)
1	100 μL	0 μL	5000
2	60 µL	40 μL	3000
3	30 μL	70 μL	1500
4	0 μL	100 μL	0

3. Transfer 20  $\mu$ L standards into separate wells of a clear, flat-bottom 96-well plate.

### Working Reagent

Fresh reconstitution of the Working Reagent is recommended.

1. Mix enough reagents for the number of assays to be performed. Prepare Working Reagents according to Table 2. For each well, prepare 85  $\mu$ L of Working Reagent.

**Table 2.** Preparation of Working Reagent

Reagent	Working Reagent
NADP/MTT Solution	8 µL
Enzyme A	1 μL
Enzyme B	1 μL
Assay Buffer	75 μL

2. Add 80  $\mu$ L of Working Reagent to each sample well. Tap plate to mix.

#### Measurement

- 1. Incubate for 10 minutes at room temperature.
- 2. Read optical density at 565 nm

## Results

- 1. Subtract the blank value (Standard #4) from the standard values.
- 2. Plot  $\triangle$ OD against standard concentrations.
- 3. Determine slope and calculate the concentration of Isocitrate in the sample using the following equation:

Isocitrate ( $\mu$ M) =

$$\frac{OD_{Sample} - OD_{Blank}}{Slope (\mu M^{-1})} \times DF \quad (\mu M)$$

Where:

 $OD_{SAMPLE} = Optical density of the sample$ 


 $OD_{BLANK}$  = Optical density of the blank

DF = Sample dilution factor

**Note**: If the calculated concentration is higher than 5000  $\mu$ M, dilute sample in water and repeat assay. Multiple the result by the dilution factor.

Unit Conversions: 1  $\mu$ M is equiv. to 189  $\mu$ g/L or 0.189 ppm isocitrate.

**Figure 1.** Typical Isocitrate standard curve.



## **Notice**

We provide information and advice to our customers on application technologies and regulatory matters to the best of our knowledge and ability, but without obligation or liability. Existing laws and regulations are to be observed in all cases by our customers. This also applies in respect to any rights of third parties. Our information and advice do not relieve our customers of their own responsibility for checking the suitability of our products for the envisaged purpose.

The information in this document is subject to change without notice and should not be construed as a commitment by the manufacturing or selling entity, or an affiliate. We assume no responsibility for any errors that may appear in this document.

#### **Technical Assistance**

Visit the tech service page at <a href="SigmaAldrich.com/techservice">SigmaAldrich.com/techservice</a>.

#### Terms and Conditions of Sale

Warranty, use restrictions, and other conditions of sale may be found at SigmaAldrich.com/terms.

#### Contact Information

For the location of the office nearest you, go to SigmaAldrich.com/offices.



4