



SMC™ Immunoassay Development Kit Instructions

Microparticle Assay

Catalog # 03-0078-00

Immunoassay kit for the quantitative determination
of **Analyte Specific SMC™ immunoassays**

FOR RESEARCH USE ONLY

NOT FOR USE IN DIAGNOSTIC PROCEDURES

Manufactured & Distributed by:



EMD Millipore Corporation
3050 Spruce Street
St. Louis, Missouri 63103
United States of America
emdmillipore.com

The M logo is a trademark of Merck KGaA,
Darmstadt, Germany.
© 2013 EMD Millipore Corporation,
Billerica, MA 01821 USA.

This page intentionally left blank.

TABLE OF CONTENTS

INTRODUCTION	2
REAGENTS	3
Reagents Provided	3
Storage Instructions	3
General Supplies Required But Not Provided	4
TECHNICAL HINTS DUE TO HIGH SENSITIVITY	5
SAMPLE INFORMATION	6
PRECAUTIONS	6
ASSAY PREPARATION	7
Coated Beads	7
Reagent Preparation	7
Sample Preparation	7
Initial Stock Standard Preparation	9
ASSAY PROCEDURE	9
Standard Curve	9
Target Capture	10
Post-Capture Wash	10
Detection	10
Pre-Transfer Wash	11
Manual Plate Transfer	11
Final Aspiration	12
Elution	12
Run on Erenna® Immunoassay System	12
APPENDIX A: SMC™ QUICK ASSAY GUIDE	13
TROUBLESHOOTING GUIDE	14
ORDERING INFORMATION	16

INTRODUCTION

The SMC™ Immunoassay uses a quantitative fluorescent sandwich immunoassay technique to measure analyte in matrix. An analyte specific capture antibody has been pre-coated onto paramagnetic microparticles (beads). The user pipettes beads, standards, and samples into uncoated microplate wells. During incubation, the analyte present in the sample binds to the capture antibody on the coated beads. Unbound molecules are washed away during the wash steps. Fluor-labeled detection antibody is added to each well and incubated. This detection antibody recognizes and binds to the analyte that has been captured onto the beads. Following a stringent wash step to remove unbound detection, the beads are briefly soaked to remove any non-specifically bound reagent. After a final aspirate, elution buffer is then added and incubated. The elution buffer dissociates the bound protein sandwich from the bead surface releasing the labeled antibodies. These antibodies are separated during transfer to a final microplate. The plate is loaded into the Erenna® or SMCxPro™ System where the labeled molecules are detected and counted. The number of fluor-labeled detection antibodies counted is directly proportional to the amount of analyte present in the sample when captured. The amount of analyte in unknown samples is interpolated from a standard curve.

FOR RESEARCH USE ONLY. NOT FOR USE IN DIAGNOSTIC PROCEDURES.

REAGENTS

The SMC™ Immunoassay Development Kit includes all reagents listed in Reagents Provided. Additional reagents and supplies may be required to run this immunoassay, as listed in the section titled General Supplies Required But Not Provided. All reagents supplied are for Research Use Only.

Reagents Provided

Item #	Description	Shipping Conditions	Storage Conditions	Component Part No.	Packaging Details
1	Discovery Standard Diluent	With cold pack	2-8°C	02-0560-00	1 x 500 mL
2	Discovery/Assay Buffer	With cold pack	2-8°C	02-0474-00	1 x 500 mL
3	10X System/Wash Buffer w/ Proclin (Note: contains 0.5% Proclin)*	With cold pack	2-8°C	02-0111-03	1 x 1L
4	Elution Buffer B	With cold pack	2-8°C	02-0297-00	1 x 100 mL
5	Buffer D	With cold pack	2-8°C	02-0368-00	1 x 100 mL

Storage Instructions

- The SMC™ Immunoassay Development Kit should be stored at 2 - 8°C.
- Discard standards after one use.
- Proper kit performance can only be guaranteed if the materials are stored properly.

REAGENTS (continued)

General Supplies Required But Not Provided Reagents

1. Erenna® 10X Wash Buffer (1 L bottle) (EMD Millipore PN 02-0111-00) if using an automated plate washer
2. Elution Buffer (EMD Millipore PN 02-0002-04) for maintenance
3. De-ionized or distilled water

Washing Options

Automated

- a. Bio-Tek ELx405™ Microplate Washer (EMD Millipore PN 95-0004-05) or
- b. Tecan HydroFlex™ microplate washer (EMD Millipore PN 95-0005-02)

Manual

- a. Sphere Mag Plate SBS Footprint (EMD Millipore PN 90-0003-02) or
- b. DynaMag™-96 Side Skirted Magnet (Thermo Fisher PN 12027)

Instrumentation / Materials

1. Jitterbug™ Microplate incubator / shaker (EMD Millipore PN 70-0009-00 or equivalent)
2. ALPS™ 50V microplate heat sealer (Thermo Fisher PN AB1443A or equivalent)
3. Centrifuge with plate rotor capable of reaching a speed of 1,100 xg
4. 12-channel pipettes capable of transferring 20 µL - 250 µL
5. 8- or 12-channel pipette capable of transferring 15 µL
6. Rotisserie rotator
7. Microcentrifuge
8. MultiScreen^{HTS} BV 96-Well Filter Plate (EMD Millipore PN MSBVN1210 or equivalent)
9. 96-well V-bottom polypropylene plate, 500 µL (Axygen PN P-96-450V-C)
10. 384-well round bottom polypropylene plate, 120 µL (Thermo Fisher PN 264573)
11. 0.2 µm syringe filter (EMD Millipore PN SLGPR33RS or equivalent)
12. Universal plate cover (Thermo Fisher PN 253623 or equivalent)
13. Sealing tape (Thermo Fisher PN 236366 or equivalent)
14. Heat sealing plate foil (EMD Millipore PN 02-01-0216-00 or equivalent)
15. 12-channel reagent reservoirs for preparing standards
16. 5 mL syringe
17. Microcentrifuge tubes
18. Container capable of holding 300 mL
19. 500 mL graduated cylinder

(Please contact your technical services representative for additional information or assistance selecting required but not provided supplies.)

TECHNICAL HINTS DUE TO HIGH SENSITIVITY

To obtain reliable and reproducible results, the operator should carefully read this entire manual and fully understand all aspects of each assay step before running the assay. The following notes should be reviewed and understood before the assay is set-up.

- Wipe down bench and pipettes with 70% isopropanol before use. It is important to allow all reagents to warm to room temperature (20 - 25°C).
- Use sterile filter pipette tips and reagent trays to avoid contamination.
- Use filter tips while transferring standard.
- Pre-wet tips (aspirate and dispense within well) twice before each transfer.
- The standards prepared by serial dilution must be used within 10 minutes of preparation. It is recommended that the standards are prepared as the last step prior to plate setup.
- The detection antibody is light sensitive and must be protected from light at all times.
- Incomplete washing can adversely affect the assay outcome. All washing must be performed with the wash buffer provided.
- If samples fall outside the dynamic range of the assay, further dilute the samples with the appropriate diluent and repeat the assay.
- The plates should be read immediately after the assay is finished. If, however, the plate cannot be read immediately, seal the plate with the pierceable foil seal and store the plate at 2-8°C for up to 48 hrs. Bring to room temperature then centrifuge the plate at 1,100 x g for 5 minutes prior to reading on the Erenna.
- The plate shaker should be set at a speed to provide maximum orbital mixing without splashing liquid on the sealer or outside the wells. For the recommended plate shaker, this would be a setting of 3 - 5.
- For optimal instrument performance, complete a cycle routine (10,000 µL at 1,000 µL/min) followed by a bubble test, and an instrument calibration prior to reading the plate.
- If a clean routine is required, run using three wells of elution buffer (EMD Millipore PN 02-0002-04), one well of 10% bleach and five wells of elution buffer (EMD Millipore PN 02-0002-04). (Note: This elution buffer is not provided and should be ordered separately.)

SAMPLE INFORMATION

- Ensure sample is clear of precipitants and other visible particulate matter before testing with the SMC™ Immunoassay.

PRECAUTIONS

- Use caution when handling biological samples. Wear protective clothing and gloves.
- Proclin-containing solutions and their containers must be disposed of in a safe way and in accordance with local, regional and national regulations.
- The chemical, physical and toxicological properties Proclin 950 at 5% have not been thoroughly investigated. At this concentration, this biocidal preservative is irritating to eyes and skin, and may be detrimental if enough is ingested (quantities above those found in the kit). ProClin 950 is a potential sensitizer by skin contact; prolonged or repeated exposure may cause allergic reaction in certain sensitive individuals. The potential for these adverse health effects is unknown for the highly diluted, small volume of ProClin in this kit, but unlikely if handled appropriately with the requisite good laboratory practices and universal precautions. For full concentration information, please refer to the SDS.
- Components of this reagent kit contain approximately 0.1% sodium azide as a preservative. Sodium azide is a toxic and dangerous compound when combined with acids or metals. Solutions containing sodium azide should be disposed of properly.

Full Hazardous Label:

Ingredient, Cat #	Full Label
02-0111-03	10X System/ Wash Buffer w/Proclin  Warning. Causes serious eye irritation. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

ASSAY PREPARATION

Coated Beads

It is possible to adjust the coating concentration of the antibody to the bead to achieve a desired specification. The Derivatization service provides the beads at 25 µg/mg but the concentration can be changed when performing the labeling yourself; step 2 Coating the Microparticles of 05-0440-00 SMC™ Capture Antibody labeling Kit Instructions 03-0077-00

1. Perform a matrix to determine the best coating concentration needed for the assay

Determine the volume of bead and Detection Antibody per well to achieve optimal assay condition

Bead loss may occur if < 5 µg of microparticles (MP) per well is used.

Analyte concentration should be determined based on estimated mid-range signal (~10x desired LLoQ).

2. Utilize the below matrix to determine Detection Antibody to Microparticle concentration

	1	2	3	4	5	6	7	8	9	10	11	12	[analyte] pg/mL	µg MPs/well	[cAb] µg/MP
A										10					
B										0				5	
C										10					12.5
D										0					
E										10					
F										0				5	
G										10					
H										0				10	
	50			100				500			1000				[detAb] ng/mL

Reagent Preparation

1. Warm the following reagents to room temperature prior to use: Standard Diluent, Assay Buffer, Coated Beads, Elution Buffer B, Buffer D, Detection Antibody and 10X Wash Buffer.
2. Store the Detection Antibody away from light until ready to use.
3. Prepare 1X Wash Buffer (from 10X Wash Buffer) as required for use on the Microplate washer and for plate 1 to plate 2 transfer.
4. Mix the Coated Beads (coated microparticles) on a rotisserie spin rotator, or manually by repeat inversion, for 10 - 20 minutes until all beads are completely resuspended.

ASSAY PREPARATION (continued)

Sample Preparation

1. Prepare samples by one of the following methods:
 - a. If using a filter plate with prefilter (EMD Millipore PN MSBVN1210 or equivalent): Stack the filter plate on top of a 96-well receptacle plate. Place \leq 200 μ L of sample into a filter plate well and spin for \geq 10 minutes at 1,100 x g.
 - b. If using a microcentrifuge: Centrifuge samples at $>13,000$ x g for 10 minutes immediately prior to use. Carefully pipette the supernatant into a clean microcentrifuge tube, avoiding particulates and slowly aspirating below the lipid layer.


Initial Standard Stock Preparation

1. Quick spin the Standard Analyte vial in a microcentrifuge and pipette mix prior to preparing standards. Use care when opening the stock standard vial to prevent loss of materials and contamination of specimens or plates with aerosols.
2. Refer to the standard value assignment on the Certificate of Analysis for the starting concentration of the Standard Analyte in the vial.
3. To make your Analyte Working Stock, perform the necessary serial dilutions, in Standard Diluent, to achieve the desired final working concentration of 1,000 pg/mL in a 1 mL final volume. Ensure that all pipetting steps transfer \geq 10 μ L of liquid to achieve the best precision.
4. Discard standard after one use.

ASSAY PROCEDURE

Standard Curve

Set the range of the Standard curve to encompass the expected endogenous level of the analyte. Prepare the standard curve dilutions in a 12-channel reservoir. Perform 1:2 serial dilutions of the Analyte Working Stock for standards 2 through 11. Run the standards in triplicate. Schematic below is an example:



1. Add 500 µL Standard Diluent to wells 2 through 12 of a 12-channel reservoir.
2. Add 1,000 µL of the Analyte Working Stock from standard preparation into well 1.
3. Transfer 500 µL from well 1 into well 2, mixing thoroughly. Continue serial dilutions from well 2, stopping at well 11, mixing thoroughly each time. Use a fresh tip with each transfer.

ASSAY PROCEDURE (continued)

Target Capture

1. Pipette 100 μ L per well of Standards or Samples to Plate 1 (96-well polypropylene).
2. Mix microparticles (coated beads) by gentle inversion until all beads are completely resuspended.
3. Immediately before adding to the assay plate, prepare Coated Beads to the desired concentration in the supplied Assay Buffer. Mix by gentle inversion. Ensure that all beads have been transferred.
4. Pipette 100 μ L per well of the Coated Beads into Plate 1.
5. Cover Plate 1 with a plate sealing film.
6. Incubate for 2 hours at 25°C on microplate incubator / shaker (if using EMD Millipore PN 70-0009-00, use setting # 5).
7. Approximately 10 minutes prior to the end of Target Capture incubation, prepare the Detection Antibody to the desired concentration in Assay Buffer. Filter the diluted detection antibody using the syringe with a 0.2 μ m filter into a clean tube.
8. When target capture incubation is complete, carefully remove temporary plate cover to avoid splashing.

Post-Capture Wash

The plate can be washed with a plate washer or a manual washer.

1. **Plate Washer**
 - a. BioTek; Post Capture Wash (POSTCAP)
 - b. HydroFlex; Post Capture Wash (PCW)
2. **Manual Post-Capture Wash Protocol**
 - a. Place Plate 1 onto magnet (EMD Millipore PN 90-0003-02).
 - b. Wait 2 minutes for beads to settle (ensure all beads are amassed as a pellet near magnet).
 - c. Aspirate the supernatant (beads remain visible).
 - d. Add 200 μ L of Wash Buffer.
 - e. Wait \geq 2 minutes. To ensure that the beads remain amassed, do not suspend or remove beads from the magnet during this time.
 - f. Aspirate buffer.

Detection

1. Immediately remove Plate 1 from the magnet and add 20 μ L per well of Detection Antibody.
2. Cover Plate 1 with plate sealing film.
3. Incubate for 1 hour at 25°C on microplate incubator / shaker (if using EMD Millipore PN 70-0009-00, use setting # 5).
4. Carefully remove plate sealing film to avoid splashing.

ASSAY PROCEDURE (continued)

Pre-Transfer Wash

The plate can be washed with a plate washer or a manual washer.

1. Plate Washer

- a. BioTek; 4 cycle Pre-Transfer (4CYCPRE)
- b. HydroFlex; 4 cycle Pre-Transfer (4cyPrTra)

2. Manual Pre-Transfer Wash Protocol

- a. Place Plate 1 onto magnet (EMD Millipore PN 90-0003-02).
- b. Add 100 μ L of Wash Buffer to each well of Plate 1.
- c. Wait 2 minutes.
- d. Aspirate the supernatant and discard into waste, change tips.
- e. Add 200 μ L of Wash Buffer to each well.
- f. Wait \geq 2 minutes. To ensure that the beads remain amassed, do not suspend or remove beads from the magnet during this time.
- g. Aspirate buffer from each well, discard into waste and change tips.
- h. Repeat steps e - g three more times for a total of four washes.
- i. Add 200 μ L of Wash Buffer to each well of Plate 1.
- j. Remove Plate 1 from magnet.
- k. Place plate on microplate incubator / shaker for 1.5 - 2 minutes to remove any NSB

Final Aspiration

1. Plate Washer

- a. BioTek; Final Aspirate (FINASP)
- b. HydroFlex; Final Aspirate (FA_V1)

2. Manual Final Wash Aspirate

- a. While Plate 1 is on the magnet, wait 2 minutes.
- b. Aspirate the supernatant and discard into waste.

Elution

1. Immediately remove Plate 1 from the magnet.
2. Add 11 μ L Elution Buffer B per well.
3. Cover Plate 1 with a plate sealing film.
4. Incubate plate for 10 minutes at 25°C on microplate incubator / shaker (if using EMD Millipore PN 70-0009-00, use setting # 5).
5. Add 10 μ L per well of Buffer D to Plate 2 (384-well polypropylene plate (Nunc PN 264573 or equivalent)) using a 12-channel manual P20.
6. Place Plate 1 on sphere magnet bed (EMD Millipore PN 90-0003-02), remove plate sealing film, and allow beads to form a tight pellet for 2 minutes.


7. Set manual 8-channel pipette to 10 μ L and transfer eluate to Plate 2 by rows, avoiding the pelleted beads.
8. Cover Plate 2 with a universal plate cover and spin plate for 5 minutes at RT, approximately 1,100 x g.
9. Cover Plate 2 with heat sealing foil (EMD Millipore PN 02-01-0216-00 or equivalent), according to manufacturer's instructions for the heat sealer.

Run on Erenna[®] Immunoassay System


1. Load completed assay Plate 2 onto the Erenna[®] or SMCxPro[™] Immunoassay System.

APPENDIX A: SMC™ Quick Assay Guide


1. Prepare all reagents, standard curve, and samples as instructed.
2. Add 100 μ L of Standard/Samples and 100 μ L of **Coated Beads** to **Plate 1**.
3. Cover and incubate for 2 hours at 25°C on microplate incubator/shaker.



4. Perform Post-Capture Wash (**Plate 1**).
5. Remove from magnet and add 20 μ L of **Detection Antibody** per well.
6. Cover and incubate for 1 hour at 25°C on microplate incubator/shaker.



7. Perform Pre-Transfer Post-Detection Wash
8. Soak 1.5 min on microplate incubator/shaker
9. Perform Final Aspiration
10. Remove from magnet and add 11 μ L of **Elution Buffer B** to each well.
11. Cover and incubate for 10 minutes at 25°C on microplate incubator/shaker.



12. Add 10 μ L of **Buffer D** per well to **Plate 2**.
13. Transfer contents of **Plate 1** to **Plate 2**.
14. Cover and centrifuge for 5 minutes at 1,100 x g.
15. Cover **Plate 2** with pierceable plate seal cover.



LOAD ON ERENNAS® SYSTEM

TROUBLESHOOTING GUIDE

Problem	Probable Cause	Solution
Background is too high	Background wells were contaminated	<p>Avoid cross-well contamination by using sealer appropriately and pipetting with multichannel pipets without touching reagent in plate. Change tips when adding reagents if cross contamination is expected.</p>
		Ensure reagents (including wash and system buffers) are not contaminated.
		Change tips for each dilution of the standard curve.
		Insufficient washes—washer may need to be cleaned or reprogrammed.
	Instrument needs cleaning	See Technical Guidelines for appropriate Erenna® cleaning protocol.
Sample variability is high	Plate was over-incubated	Confirm correct incubation times were followed.
	Multichannel pipet may not be calibrated	Calibrate pipets.
	Plate washing was not uniform	Confirm that there is no residual left in the wells following post-capture wash step and Final Aspirate. Ensure that you have < 2 μ L or residual remaining in the well.
	Samples may have high particulate matter or other interfering substances	Samples should be centrifuged or filtered according to the PI and lab SOPs. Unprocessed samples could lead to higher imprecision.
	Plate agitation was insufficient	Plate should be agitated during all incubation steps using a vertical plate shaker at a speed where beads are in constant motion without causing splashing (~650 - 1000 RPM).
Cross-well contamination		Ensure that the plate is sealed well at each incubation step. Should splashing occur on the plate sealer pulse spin plate to remove excess material prior to removing the seal. A new plate seal should be used every time the plate is sealed.

TROUBLESHOOTING GUIDE (continued)

Problem	Probable Cause	Solution
Sample variability is high (continued)	Cross-well contamination (continued)	Care should be taken when using same pipet tips that are used for reagent additions and that pipet tip does not touch reagent in plate.
Beads are lost during the wash	Plate washer needs optimization/cleaning	Contact Tech Support or local BCS to schedule washer programming. Refer to user guide for cleaning procedure.
	Insufficiently primed washer	Washer should be primed with wash buffer prior to running the post capture wash protocol.
	Beads came in contact with water	Washer should be primed with wash buffer sufficiently prior to plate wash. Viscosity of water changes the performance of the magnetic particles.
	Proper magnet was not used	Ensure that the mag plate (EMD Millipore PN 90-0003-02) was present on plate wash stage prior to running wash protocol.
Published LLoQ was not achieved	Improper dilution/reconstitution of the standard reference material	Confirm appropriate kit protocol was followed when preparing standard curve.
		Check plate washer to confirm no beads were lost during washes and that plate contains <2 uL following the post-capture and final aspiration protocols.
		Ensure time from thawing the standard to starting the capture incubation is ≤10 minutes
Microparticles do not resuspend into homogenous solution	Beads were not properly stored and may have been frozen	Labelled microparticles should be stored at 4°C. If microparticles are frozen they will not resuspend properly.
	Samples may be causing interference due to excess particulate matter	Samples should be properly processed prior to testing to remove particulate matter/lipids.

ORDERING INFORMATION

To place an order or to obtain additional information about SMC™ products, please contact your Customer Service or Technical Support Specialist.

Contact information for each region can be found on our website:

emdmillipore.com/contact

Conditions of Sale

For Research Use Only. Not for Use in Diagnostic Procedures.

Safety Data Sheets (SDS)

Safety Data Sheets for EMD Millipore products may be ordered by fax or phone or through our website at emdmillipore.com/msds

This page intentionally left blank.



EMD Millipore Corporation
3050 Spruce Street
St. Louis, Missouri 63103
United States of America

Toll-Free US: (800) 645-5476
Fax: (800) 645-5439
emdmillipore.com